



CHECKPOINT DUSTITE LR

Distributed
by

SCHRADER
INTERNATIONAL

Pressure to perfection

LOOSE WHEEL NUT INDICATORS
WHEEL OVERHEAT INDICATORS


CHECKPOINT



CHECKPOINT are loose wheel nut indicators. These are fixed to the wheel nut which allows any movements of the wheel nut to be noted visually.

When introduced into the safety procedures of any transport or bus company, CHECKPOINT indicators will improve the maintenance of brakes, bearings, studs and wheel nuts. The indicators reduce the risk of wheel detachment along with problems related to overheating in the wheel.

The size in millimetres corresponds to the distance across the flats of the nut. This size is indicated on the products. The products are made from a special grade of plastic which commences melting from 120°C.



The CHECKPOINT is easily fitted to the wheelnut, and is reusable.

65910- 69	Pack of 100 CHECKPOINT Ø 27mm
65911-69	Pack of 100 CHECKPOINT Ø 30 mm
65912- 69	Pack of 100 CHECKPOINT Ø 32 mm
65913- 69	Pack of 100 CHECKPOINT Ø 33 mm

The DUSTITE LR is both an indicator and a dust cap; along with all the functions of the CHECKPOINT, the DUSTITE LR also protects the nut/stud from dirt and salt. It is designed to be fitted through a step ring or rim.

DUSTITE LR



- If the CHECKPOINT or DUSTITE LR moves out of pattern, this indicates a potential loose wheelnut situation.
- If the CHECKPOINT or DUSTITE LR starts to deform or melt, this indicates a potential hot wheel situation (Faulty brakes, worn bearings etc)



Push the DUSTITE LR into the wheel nuts.
The indicator is reusable.

65914-71	Pack of 50 DUSTITE LR Ø 32mm
65915-71	Pack of 50 DUSTITE LR Ø 33mm



Schrader s.a.s.,
BP 29 - 48, Rue de Salins,
F 25301 PONTARLIER Cedex, France
Service Clients/ Customer Department:
Tel.: +33 381.38.56.50
Fax: +33 381.38.56.81
Email: resale.info@schrader.fr
www.schrader.fr